

TESS 1 Wireless Installation Instructions

Pin# 1 - Tee into the ground side of the PTO light wire allowing the engagement of the PTO to activate the TESS I Control System or to chassis ground.

Pin# 2 - To ECM switched feed wire. (See Note 1)

Pin# 3 - Refer to the ECM Guide Sheet.

Pin# 4 - To Emergency Hydraulic Pump Relay.

Pin# 5 - Tee into the starter wire from the key switch.

Pin# 6 - Refer to the ECM Guide Sheet

Pin# 7 - To ECM switched feed wire. (See Note 1)

Pin# 8 - Refer to the ECM Guide Sheet.

Pin# 9 - 12 volt ignition fused. (15 amps) or to a on/off switch (PTO).

Pin# 10- 12 volt ignition fused. (15 amps) or to a on/off switch (PTO).

1)Note: The ECM switched feed wire has to be cut. The one wire will be joined to pin# 2 and the other wire will be joined to pin# 7.

2)Note: Interlocks can be install in pin# 1 and/or pin# 9 and/or pin# 10.

RPM Control Co.
519-758-7901
886-519-9817